Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110

Instructions for #80972 Uncoupling Tool

This uncoupling tool provides a convenient way of uncoupling cars at any location on your model railroad. To uncouple, gently push the cars together so that there is slack in the couplers. Place the tip of the uncoupling tool between the hooks of the couplers and gently twist.

To protect your pocket, store the tool in its sleeve.

Micro-Mark®

Tech Support: 908-464-1094
MMTechService@micromark.com

MM021110