



INSTRUCTIONS FOR #81387 MOUNTING PLATE

The #81387 Saw Mounting Plate may be used to mount the following saws to the edge of your workbench: #60514 MicroLux Multi-Saw, #50304 MicroLux 2" Table Saw, #80463 Tilt Arbor Table Saw, #87775 MicroLux Miniature Table Saw and #87776 MicroLux Variable Speed Multi-Saw. To use with #87775 and #87776, refer to the instructions included with those machines.



To mount either the #60514 MicroLux Multi-Saw or the #50304 MicroLux 2" Table Saw, use the 3 long screws and washers provided to attach the plate to the bottom of the saw housing, as shown in Figure A.



To mount the #80463 Tilt Arbor Table Saw, use the four short screws provided to attach the plate to the bottom of the saw housing, as shown in Figure B.

When mounting the saw to your workbench, be sure to turn the clamping screws just enough to secure the bracket and saw. Over-tightening the screws may distort the bracket.

If the edge of your workbench is very thin, put a small shim strip under the workbench top so that the clamps can secure the bracket properly.

Micro-Mark®
THE SMALL TOOL SPECIALISTS

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support: MMTechService@micromark.com • www.micromark.com

MM111820