
## #82570 TOOL REST AND SPUR DRIVER



Install Tool Rest in Tool Post as shown. Tighten Cap Screws securely.

