



Item no	Description
1	Screw M6*14
2	Rubber pad
3	Screw M4*10
4	Baseplate
5	Support block
6	Screw M4*12
7	Adjust blot
8	Check ring 12
9	Spindle pulley
10	Oil cup 6
11	Belt J*353*8
12	Nut M8
13	Adjust screw
14	Damping pad I
15	Screw M3*6
16	Dusrproof plate
17	Suck dirt port
18	Washer 3
19	Screw M3*5
20	Check ring 8
21	Motor pully
22	Spacer
23	Motor connect plate
24	Showing label
25	Protect cover
26	Electromagnetism switch
27	Nut M4
28	Commute bridge
29	Screw M4*20
30	Overload current protect
31	Power line
32	Lock connecter
33	Main label
34	Screw M4*12
35	Washer 4
36	Endcover
37	Metallurgy bearing
38	Adjust mat
39	Notch round nut M14*1.5
40	Mat
41	Emery cloth
42	Motor
43	Key 3*16
44	Screw M5*16
45	Screw M5*6

46	Spring washer
47	Lock washer 5
48	Ball head screw
49	key 3*8
50	Round pin B2*6
51	Rubber Drum
52	Big washer
53	Spindle
54	Bracket base
55	Adjust handwheel
56	Adjust mat II
57	Keep off plate
58	Worktable
59	Fixed shaft
60	Fixed support
61	Screw M4*16