

84656 Product Note:

YOUR FIRST STEP TO USING YOUR NEW SAW

It is prudent and good tool practice that before using any power tool, especially a saw, that it is ready in all respects to begin using. Please read the safety instructions provided in your tool manual.

Next, you will need to ensure that the blade is mounted and secured in position on the arbor shaft PRIOR to using! Perform this with the saw Unplugged.

To do this you will need the 2 hex wrenches provided with your saw and an adjustable wrench or a 7mm socket driver.

Remove the 7mm lock nut that holds the aluminum arm to the clear safety shield and disconnect the arm from the screw it is on.

Grasp and slide UP on the gray blade guard with it's clear shield to remove it from the mount on the side of the housing. *Watch out for the blade because it is sharp.*

Locate the 2 hex wrenches that came with your tool. The larger one is the correct one for the center screw that is mounting the blade. The smaller one is used to lock the shaft of the blade while this screw is checked.

Tilt the unit from the front backwards so that you can see the small hole in the middle of the underside of the housing that is located in between the left and right bearing protrusions. Take the long end of your smaller hex wrench and insert it into this hole. Rotating the blade by hand, while applying upward force on the small hex wrench, you will find the hole in the shaft. Once you have found it, push the wrench up until it stops this will lock the shaft from rotating. You can now use the larger wrench and rotate the blade screw clock-wise to ensure this screw is tight. Once done, you can now remove the small hex wrench and reassemble your guards as they were. Leave the lock nut for the arm just loose enough to allow the arm to move freely when the safety button is pressed to lower the saw into item being cut.

If all else is in good order you can proceed to use your new saw. MM061620