OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309

OPERATING INSTRUCTIONS FOR #60301 MICRO-CHUCK

Insert shank of micro-chuck into rotary tool's 1/8" collet and tighten collet nut securely. Turn rotary tool on and check for balance. If chuck appears to be turning out-of-true, loosen collet nut slightly and give chuck a 1/4 turn. Continue adjusting in this manner until best balance is obtained. Recommended maximum speed: 10,000 rpm.

Micro-Mark®

340 Snyder Avenue, Berkeley Heights, NJ 07922
Tech Support 908-464-1094
www.micromark.com
MMTechService@micromark.com

MM060309