

# BATTERY INSTALLATION INSTRUCTIONS FOR #83039 DIGITAL READOUT (DRO)

Remove the battery cover on the right side of LED by removing the 2 small Phillips screws. Locate the colored ribbon inside and pull it out slightly. Insert the battery positive (+) side up with the side of the battery against the ribbon and while holding the end of the ribbon push the battery into the slot. There should be a bit of ribbon exposed as an aid in later battery replacement. Reinstall the battery cover and test the DRO's functions.

**Micro-Mark<sup>®</sup>** 340 Snyder Avenue  
Berkeley Heights, NJ 07922

Tech Support: 908-464-1094

[www.micromark.com](http://www.micromark.com) [MMTechService@micromark.com](mailto:MMTechService@micromark.com) MM011306